

KOHLER®

Roughing-In

K-13466, K-13467
ELECTRONIC FAUCET

Product Information

Applicable product:	
Electronic faucet – with mixer	K-13466
Electronic faucet – without mixer	K-13467
Optional accessories:	
Grid drain with overflow	K-7129-A
Grid drain without overflow	K-7129
4" (102 mm) escutcheon plate – square	K-13478-B
8" (203 mm) escutcheon plate – square	K-13479-B
Thermostatic mixing valve	K-13601

Installation Notes

Install this product according to the installation guide.

A 1-1/4" (32 mm) minimum to 1-1/2" (38 mm) maximum diameter mounting hole is required.

The minimum distance between the back of the faucet spout and the wall must be 1-3/4" (44 mm). This will allow proper clearance for setscrew access.

The maximum distance between the bathroom sink basin edge to the base of the faucet spout must be 1-3/4" (44 mm).

The maximum height of the lip basin should be 3/4" (19 mm).

Product includes rosebud spray aerator. Other aerator styles are available. Please contact your distributor or see Kohler.com.

Product requires two AAA batteries, which are included.

ADA, ICC/ANSI A117.1, CSA B651, OBC compliant when installed to the specific requirements of these regulations.

