

KOHLER®

Roughing-In

K-13472, K-13473
ELECTRONIC FAUCET

Product Information

Applicable product:	
Electronic faucet – with mixer	K-13472
Electronic faucet – without mixer	K-13473
Optional accessories:	
Grid drain with overflow	K-7129-A
Grid drain without overflow	K-7129
4" (102 mm) escutcheon plate – round	K-13478-A
8" (203 mm) escutcheon plate – round	K-13479-A
Thermostatic mixing valve	K-13601
Small Spray 0.38 gal/min (1.44 l/min) – Insert only	1160593
Additional flow options are available (refer to the Price Book)	

Installation Notes

Install this product according to the installation guide.

A 1-1/4" (32 mm) minimum to 1-1/2" (38 mm) diameter maximum mounting hole is required.

The minimum distance between the back of the faucet spout and the wall must be 1-3/4" (44 mm). This will allow proper clearance for setscrew access.

The maximum distance between the bathroom sink basin edge to the base of the faucet spout must be 1-3/4" (44 mm).

The maximum height of the lip basin should be 3/4" (19 mm).

Product includes rosebud spray aerator. Other aerator styles are available. Please contact your distributor or see Kohler.com.

Product requires two AAA batteries, which are included.

Additional flow options are available. Please refer to the Price Book.

ADA, ICC/ANSI A117.1, CSA B651, OBC compliant when installed to the specific requirements of these regulations.

